B&D

REMOTE ORDERING OPTIONS

Art ID:
100510



SPECIFICATIONS
B&D
Frequency - Multiple
Buttons - 4
Battery - CR2032

Art ID:
100511



SPECIFICATIONS
B&D
Frequency - Multiple
Buttons - 4
Battery - CR2032

Art ID:
MC100AML



See **page 13-14**

SPECIFICATIONS
Chamberlain
Frequency - Multiple
Buttons - 2
Battery - CR2032

COMPATIBLE WITH



062731



062871



062872




062730



70241



70241-O



70241-P



62733

RECEIVER COMPATIBILITY

- Suits Models (B&D Tri-Tran):

GDO-12 Hiro, SDO-7 Smart Pro, SDO-6 Secure, SDO-8 PanelMax, SDO-4V1 PanelPro, RDO-1V3 Roll-A-Pro, SDO-3V2 Control-A-Door, SDO-2 Prodigy, Powerdrive 62482, Powerdrive 62887

Remote Programming Steps

Programming New Remote to Receiver

1. Press the CODE SET button located on the motor once and immediately release.
2. The CODE SET LED will illuminate to indicate the opener is in learning mode (If a valid code is not stored within 15 seconds the motor will exit this mode).
3. Press any button on the NEW remote you want to code to the motor once and hold for 2 seconds then let go.
4. The CODE SET LED on the motor will begin to flash.
5. Press the same button on the NEW remote for 2 seconds.
6. The CODE SET LED will illuminate for one second and then go out.
7. Repeat all the steps above if you have any additional

Deleting a All Remotes from Receiver

1. Turn the power off to the receiver (garage door motor).
2. Press and hold CODE SET button.
3. While holding CODE SET turn power on again. After 15 seconds the Coding LED will light up to indicate that the receiver's memory has been cleared.
4. Release CODE SET . All the stored codes should now be deleted.

Whilst every effort has been made to ensure the accuracy of the information supplied herein, we assume no liability for any errors or omissions. Information contained in this document is subject to change without prior notice.