MITTO-4C

Battery: CR2032

ORDERING OPTIONS

Ⓖ



Art.
MITTO-4C

SPECIFICATIONS
BFT Mitto 4C
Frequency - 433Mhz
Buttons - 4

Ⓐ



Art.
M-BT
See **page 66** for programming instructions

COMPATIBLE WITH



BRCB04



BRCB02



MITTO2



MITTO4



MITTO4-B



TRC1



TRC2



TRC4



MITTO4US



MITTO2A



MITTO4A

RECEIVER COMPATIBILITY

- Suits Models:

BFT Garage & Gate Receivers.

Remote Programming Steps

Program Existing Remote to New Remote

1. **If the existing remote is from the OLD MITTO range**
   Press the hidden button on the back of the existing remote with a pin. Press and hold the button that operates the receiver (garage door motor) for 2 seconds.

   If the existing remote is the MITTO-4C
   Press and hold the Buttons 'B1 & B2' [Top 2 buttons on remote] until the LED turns on. Press and hold the button that operates the receiver (garage door motor) for 2 seconds.

2. On the new remote, press and hold the Buttons 'B1 & B2' [Top 2 buttons on remote] until the LED turns on. Press and hold the button you would like to operate the receiver (garage door motor) for 2 seconds.

Program Remote to Receiver without display screen

Note: You must have one existing remote programmed to the receiver (garage door motor).

1. Press 'SW1' button on the receiver board (garage door motor). The LED will start to flash.
2. On your new remote, press and hold the Buttons 'B1 & B2' [Top 2 buttons on remote] until the LED turns on. The receiver's (garage door motor) LED will turn off.
3. Press and hold the remote button you would like to operate the receiver (garage door motor) for 2 seconds. The receiver's (garage door motor) LED will start to flash quickly.
4. Wait 15 seconds and the new remote will be programmed.

Program Remote to Receiver with display screen

Note: You must have one existing remote programmed to the receiver (garage door motor).

1. Press the 'OK' button twice on the receiver (garage door motor). Screen will display 'PARA'.
2. Press the '-' button twice on the receiver (garage door motor). Screen will display 'RADIO'.
3. Press the 'OK' button twice on the receiver (garage door motor). Screen will display 'Hidden Button'.
4. On your new remote, press and hold the Buttons 'B1 & B2' [Top 2 buttons on remote] until the screen displays 'Released'. The screen will now display 'Desired Button'.
5. Press the remote button you would like to operate the receiver (garage door motor) for 1 second. Screen will display 'OK'.

Whilst every effort has been made to ensure the accuracy of the information supplied herein, we assume no liability for any errors or omissions. Information contained in this document is subject to change without prior notice.