MERLIN

REMOTE ORDERING OPTIONS

Art ID:
M-802



SPECIFICATIONS
Merlin
Frequency - 40Mhz
Buttons - 2
Battery - 4LR44

COMPATIBLE WITH


M804


M800


M2100

RECEIVER COMPATIBILITY

- Suits Models:

Merlin M-500, M-501 & M-502, M230T, M430R,P-230T receivers

Remote Programming Steps

Programming New Remotes

1. Locate the dip switches on the receiver (garage door motor) usually hidden by a small black cover.
2. Remove the visor clip and battery cover from the new remote control.
3. Locate the dip switches in the new remote control.
4. Match the dip switches in the new remote control to the code switches in the opener. (DO NOT CHANGE THE CODE SWITCHES IN THE OPENER).
5. Alternatively, if you have an existing remote control, you can match the dip switches in the new remote control to the DIP switches in the existing remote control.

Delete All Remotes (Clear Lost Remotes)

1. Change the positioning of the 12-way DIP switches in the receiver (garage door motor).

Whilst every effort has been made to ensure the accuracy of the information supplied herein, we assume no liability for any errors or omissions. Information contained in this document is subject to change without prior notice.