GLIDEROL

REMOTE ORDERING OPTIONS

Art ID:
TM-27



SPECIFICATIONS
Gliderol
Frequency - 27Mhz
Buttons - 1
Battery - LR23A

COMPATIBLE WITH



GTX1



GTX2



GTX3



This programming is for Green Circuit Board Versions Only

RECEIVER COMPATIBILITY

- Suits Models:

All compatible Glidermatic & Glidermatic Deluxe Roller Door Operators (must have dipswitches).

Remote Programming Steps

Programming New Remotes to Receiver (9 DIP switch)

1. To program the remote, just match the 9 DIP switch from any existing remote.

Programming New Remotes to Receiver (2x 8 DIP switch)

If your receiver has two 8 digit codes inside their Control Box, you will need to fill out the information below using the 'Binary to Trinary Conversion' table as reference.

Binary to Trinary Conversion Table

BINARY SWITCH A	UP	UP	DOWN	DOWN
BINARY SWITCH B	UP	DOWN	UP	DOWN
HANDSET (TRINARY) SWITCH	DOWN	UP	MIDDLE	MIDDLE

1. Fill out the following details below from the 2 Binary Switches from the Control Box.

Binary Switch A

1	2	3	4	5	6	7	8

Binary Switch B

1	2	3	4	5	6	7	8

2. Using the 'Binary to Trinary Conversion' table as reference, fill out the 'Handset' results below.

NOTE: The results from comparing the Binary Switches A & B are not the same order in the Handset (Remote) results.

Handset Code

1	2	3	4	5	6	7	8	9
								DOWN

3. Input the results from the Handset Code onto your Remote.

Whilst every effort has been made to ensure the accuracy of the information supplied herein, we assume no liability for any errors or omissions. Information contained in this document is subject to change without prior notice.