

REMOTE ORDERING OPTIONS

<p>Art ID: E970M</p>  <p>SPECIFICATIONS Merlin Frequency - 433Mhz Buttons - 4 Battery - CR2032</p>	<p>Art ID: E980M</p>  <p>SPECIFICATIONS Merlin Frequency - 433Mhz Buttons - 4 Battery - CR2032</p>	<p>Art ID: E148M</p>  <p>SPECIFICATIONS Merlin Frequency - Multiple Buttons - 4 Battery - CR2032</p>
<p>Art ID: E964M</p>  <p>SPECIFICATIONS Merlin Cloning remote Buttons - 4 Battery - CR2032</p>	<p>Art ID: E960M</p>  <p>SPECIFICATIONS Merlin Frequency - Multiple Buttons - 4 Battery - CR2032</p>	<p>Art ID: MC100AML</p>  <p>See page 13-14 SPECIFICATIONS Chamberlain Frequency - Multiple Buttons - 2 Battery - CR2032</p>

COMPATIBLE WITH



RECEIVER COMPATIBILITY

• Suits Models:

CR625EVO, CR655MYQ, CS60EVO, CS100EVO, MR550EVO, MR650EVO, MR655MYQ, MR850EVO, MR855EVO, MR855MYQ, MJ3800MYQ, MS65MYQ, MS105MYQ, MT110MYQ, MS125MYQ, MT3850EVO, MT100EVO, MT120EVO, MT50EVO, MT60EVO, MRC950EVO, ST50EVO, ST50EVO LM800AMT, MGA600 XLR8, MGL300, MGL400, MGS300, MGS500, MGS500T, MGS1000, MGS1000T, MJ3800, MJ3800R, ML500, ML700, ML750, MLR500, MLR750, MLR850, MR60, MR600, MR600A, MR650, MR800, MR800A, MR850, MR1000, MT60, MT60P, MT230, MT600, MT800, MT1000, MT3850, MT5580, MT5580P, MR850, MR1000,

Remote Programming Steps

Programming Remotes - Merlin Security +

1. Enter "Programming Mode" on the remote by holding down the middle left & right buttons at the same time for 5 seconds.
2. Press the "Learn" button on the garage door motor.
3. Press a button on the remote you wish to program until the light flashes on the garage door motor.
4. Now press any "other" button on the remote to "Lock in" the programming. The remote LED will turn off.

Programming Remotes - Merlin Security +2.0

1. Press and hold any remote button you wish to open the garage/gate with.
2. Press and release the "Learn" button on the garage door motor panel. The opener light will flash once. Release the remote button.

Deleting All Remotes from Receiver

1. Push "Learn/Delete" button for 12 seconds – or until the indicator lights switch off.