MARANTEC


REMOTE ORDERING OPTIONS

Art ID:
D382



SPECIFICATIONS
Marantec
Frequency - 433Mhz
Buttons - 2
Battery -CR2032

Art ID:
M-BT



See **page 30-32**

SPECIFICATIONS
JMA
Cloning remote
Buttons - 4
Battery - CR2032

Art ID:
M-LT



See **page 30-32**

SPECIFICATIONS
JMA
Cloning remote (FIXED CODE)
Buttons - 4
Battery - CR2032

COMPATIBLE WITH



D302



D313



D304

RECEIVER COMPATIBILITY


- Suits Models:

Marantec AZ021, 64176, Comfort 220, Comfort 250, Comfort 252, Comfort 270, Comfort 280, Digital 302, Digital 304, Digital 313

Remote Programming Steps

Programming New Remote to Receiver

1. On the receiver circuit board, press the button 'CH1' and release. The LED light L1 will blink.



2. Press and hold any button on the new remote. The LED light L1 will stop blinking and stay on.

3. Release button on the new remote

Programming Existing Remote to New Remote



1. Connect your existing remote to your new remote with the supplied connection clip.

2. Press and hold any button on your existing remote. The LED light on your new remote will light up.

3. While holding the button on your existing remote, press and hold the button you wish to program on your new remote. The LED light on your new remote will blink then stay on.

Whilst every effort has been made to ensure the accuracy of the information supplied herein, we assume no liability for any errors or omissions. Information contained in this document is subject to change without prior notice.