DITEC

REMOTE ORDERING OPTIONS

Art ID:
SLIM4E-DC




SPECIFICATIONS
DITEC
Frequency - 433Mhz
Buttons - 4
Battery - CrR032

Art ID:
SGT200



SPECIFICATIONS
>>>SGT
Frequency - 433Mhz
Buttons - 4
Battery - LR27A


Art ID:
M-BT



See **page 30-32**

SPECIFICATIONS
JMA
Cloning remote
Buttons - 4
Battery - CR2032

Art ID:
M-LT



See **page 30-32**

SPECIFICATIONS
JMA
Cloning remote (FIXED CODE)
Buttons - 4
Battery - CR2032

COMPATIBLE WITH



GOL4



LG4



LP2-G



LS2



LP2-R



ZEN4

RECEIVER COMPATIBILITY

- Suits Models:

DITEC BIXLG4, BIXLP2, BIXLS2, GOL4, ZEN4, LG4, LP2-G, LS2, LP2-R

Remote Programming Steps

Programming Remote direct to receiver

1. Press on the 'PRG' button on the receiver board (A light should turn on)
2. Press button on NEW Remote you wish to program
3. Wait 10 seconds to finalise programing

Programming Remote from existing Remote

1. Stand within 5 – 10 meters of gate/garage
2. Hold top and bottom buttons for 3 seconds on the existing remote (LED should turn on)
3. Hold top and bottom buttons for 3 seconds on the existing remote again (LED Should flash for 2 seconds)
4. Press button you wish to program on new remote
5. Wait 10 seconds to finalise programing

Deleting Remote Controls from your Motor

1. Hold the 'PRG' button on the receiver for approx. 3 seconds. The signal LED should flash

To erase all remotes
Continue holding the 'PRG" button for another 3 seconds

To erase just 1 remote
Press the button on the remote you wish to erase

Whilst every effort has been made to ensure the accuracy of the information supplied herein, we assume no liability for any errors or omissions. Information contained in this document is subject to change without prior notice.