STEEL-LINE

REMOTE ORDERING OPTIONS

Art ID:
ZT-07



SPECIFICATIONS
Steel-line
Frequency - 433Mhz
Buttons - 4
Battery - LR27A

COMPATIBLE WITH

RECEIVER COMPATIBILITY

- Suits Models:

Steelline SD800, SD1200, 800SD, 1200S

Remote Programming Steps

Programming Remote to motor

1. Press and hold the 'P' and '+' buttons on the motor until all lights on the motor turn on and LED 7 flashes
2. Press the '+' button on the motor once (all LED lights turn off except LED 7)
3. Quickly press and release the desired button on your new remote twice (all LED lights turn on and LED 7 will begin flashing)
4. Press the 'P' button once on the motor to save (LED 3 will switch on indicating that the remote has been successfully programmed)
5. Repeat above procedure for all additional handsets.

Delete All Remotes

1. Press and hold the 'P' and '+' buttons on the motor until all lights turn on and 'LED 7' flashes
2. Press and hold the '-' button until 'LED 7' turns off and begins flashing again
3. Press the 'P' button once to save ('LED 3' will switch on indicating that all codes have been deleted and that the opener is now in normal operating mode)

Whilst every effort has been made to ensure the accuracy of the information supplied herein, we assume no liability for any errors or omissions. Information contained in this document is subject to change without prior notice.