STODDART

REMOTE ORDERING OPTIONS

Art ID:
SGT260



SPECIFICATIONS
>>>SGT
Frequency -433Mhz
Buttons - 4
Battery - LR27A

COMPATIBLE WITH



RPG485

RECEIVER COMPATIBILITY

- Suits Models:

T5/500, T6/600, T8/800, T-950, T-1100, Slimfit, N3588, SDO10, SDO-21 TP/BP, RDO10, T12/S12, T12/MPS, MPS 21, DPS D12/D20, SDO-3 DC, SDO-4, SDO-P, SDO-1, SDO-21 DPS, SDO-21 MPS

Remote Programming Steps

Programming New Remote

Program Remote to Receiver

1. Press and release Red 'Learn' Button. Screen should now read 'bu'.
2. Press and Hold button on new remote that you want to operate the door until the motor light rapidly flashes then extinguishes.
3. Press button on new remote again to test.
4. Repeat steps 1 -3 to program additional remotes

Program Remote to Multiple Receivers

(Up to 4 can be programmed to one remote)

1. Delete all existing remotes on motors (refer to Delete All Remotes below).
2. Press and release Red 'Learn' Button. Screen should now read 'bu'.
3. Press and release Blue '-' Button. Screen should now read 'ru'
4. Press and Hold button on new remote that you want to operate the door until the motor light rapidly flashes then extinguishes.
5. Repeat Steps 1 & 2 on next motor and use different button on new remote to press and hold.
6. Repeat above steps until all motors are paired to remote.

Delete All Remotes

(Clear Lost Remotes)

1. Press the LEARN or CODE SET button. (LED indicator will glow solid)
2. Press and hold the black RUN button (LED indicator will begin to flash quickly)
3. Once LED stops flahing all remotes are deleted

Whilst every effort has been made to ensure the accuracy of the information supplied herein, we assume no liability for any errors or omissions. Information contained in this document is subject to change without prior notice.